

DUROMAX **Installation Instructions- QR Top only**

Step One: Bottom Section Installation

- Install bottom section centered on the front wall of the trailer flush with the floor.
- Use hex head screws included with the bulkhead and attach around outer perimeter of the bottom plastic unit.
(Screws may also be added to interior if needed)



(Use screws to install bottom section)

Step Two: Placement of top section

- Position the top section at a 45 degree angle on top of the bottom section to engage the three locking tabs.
- Tilt the top section back into position.



Step Three: Installation of Quick Release Latches

- Locate the two cut-outs on the top section, cut away tab.
- Place the latch in the cut-out and secure with the provided self tapping sheet metal screws into the front wall unit side post.
- When installed, turn the latches to secure the top section against the front wall of the trailer.



(For top section only)

*Note: over 104" high requires Center Support # 10175