

# *ITW Insulated Products*

## *UB 1*

### *Universal Bulkhead Installation Instructions*

1. **Install left panel** on roadside wall (left wall)
2. Press the cam buckle on this panel to **release flexible top on the left panel** and seal against ceiling.
3. **Install right panel** on curbside wall (right wall) in front of left panel. **Open right panel about 12 inches** and slide back against right wall.
4. **Secure Velcro strap** on left panel over the right panel.
5. **Push the right panel back into place** and this should give you a tight seal. If not, reposition panel and tighten velcro strap and push back into place.
6. Press cam buckle on right panel to **release flexible top** and seal against ceiling.

*Please review Installation Video for further instructions.*